

DATSUN PICK-UP

SERVICE MANUAL

MODEL
620 SERIES



NISSAN MOTOR CO., LTD.
TOKYO, JAPAN

QUICK REFERENCE INDEX

GENERAL INFORMATION	GI
ENGINE TUNE-UP	ET
ENGINE MECHANICAL	EM
ENGINE LUBRICATION SYSTEM	EI
COOLING SYSTEM	CO
FUEL SYSTEM	EF
ENGINE ELECTRICAL SYSTEM	EE
ENGINE REMOVAL & INSTALLATION	ER
CLUTCH	CL
TRANSMISSION	TM
AUTOMATIC TRANSMISSION	AT
PROPELLER SHAFT & DIFFERENTIAL CARRIER	PT
FRONT AXLE & FRONT SUSPENSION	FT
REAR AXLE & REAR SUSPENSION	RA
BRAKE	BR
WHEEL AND TIRE	WT
STEERING	ST
ENGINE CONTROL FUEL & EXHAUST SYSTEM	FE
BODY	BF
BODY ELECTRICAL	BE
SERVICE EQUIPMENT	SE

FOREWORD

This service manual has been prepared for the purpose of assisting service personnel of authorized NISSAN/DATSUN dealers in providing effective service and maintenance of the 1973 DATSUN PICK-UP.

Since proper maintenance and service are absolutely essential in satisfying the owners of Datsun, this manual should be carefully studied and kept in a handy place for ready reference.

This manual includes procedures for maintenance adjustments, minor service operations, removal and installation, and for disassembly and assembly of components.

The Quick Reference Index on the first page enable the reader to quickly locate the desired section. At the beginning of each individual section is a table of contents which gives the page number on which each major subject begins. A index is placed at the beginning of each major subject within the section.

Special Tools required for servicing are presented in the "SE" section.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication approval.

Rights for alteration of specifications and methods at any time are reserved.

NISSAN MOTOR CO., LTD.
TOKYO, JAPAN